

OPERATING MANUAL

JP-04red**Hand pump JP-04**

The material of the hand pump consists of polypropylene and EPDM seals.

1. Installation of the telescopic suction tube

Firmly screw the telescopic suction tube into the female thread of the lower part of the pump body. Extend telescopic suction tube to required length and firmly tighten wing nut.

2. Operation

Connect the drum adapter of the hand pump (male thread 2") that is located at the lower part of the pump body to your drum. For plastic drums and canisters adapters can be supplied.

Push the handle of the pump several times very fast and very strong up and down to build-up a water column. A minimum level of 12-15 cm in the container is necessary for the suction process.

3. Safety regulations

- **Be careful when pumping acids and caustic solutions.**
- **Never use this hand operated pump for chemicals or flammable liquids like gasoline or solvents and media of hazard class A1, A11.**
- **Comply to all safety instructions and wear necessary protective clothing (protective, glasses, gloves, apron and possibly boots).**

JESSBERGER GmbH

Jaegerweg 5-7
D-85521 Ottobrunn
Germany
Phone: +49 (0) 89 - 66 66 33 400
Fax: +49 (0) 89 - 66 66 33 411
www.jesspumpen.de
info@jesspumpen.de