

OPERATING MANUAL

JP-08

Hand pump JP-08



This hand operated pump is made of PVDF/ PTFE. The seals are made of PTFE. Therefore this pump is suitable for high aggressive chemicals.

1. Installation

The JP-08 hand pump consists of several pieces that must be assembled: pump body, suction tube, drum adapter, discharge arc, etc. The suction tube consists of 3 pieces, each with a length of 35 cm.

Firmly screw the telescopic suction tube in thread of the lower part of the pump body and assemble the drum adapter at the suction tube.

After that connect the discharge arc at pump body. This outlet can be freely rotated from 0 to 360°C.

After lubrication and assembling the pump is ready for operation.

2. Delivery rate

The hand rotating pump will bring a flow rate of 0,3 l/ rotation.

3. Lubrication

Spray into pump body a PTFE type lubricant spray. Reiterate this lubrication depending of use of pump. Hand pump should be rinsed thoroughly after each use with a suitable solvent for the material being pumped.

Be careful when pumping acids and caustic solutions!

Comply to all safety instructions and wear necessary protective clothing (protective, glasses, gloves, apron and possibly boots).

Never use this hand operated pump for flammable liquids and cleaning agent or media of hazard class A1, A11.

JESSBERGER GmbH

Jaegerweg 5-7

D-85521 Ottobrunn

Germany

Phone: +49 (0) 89 - 66 66 33 400

Fax: +49 (0) 89 - 66 66 33 411

www.jesspumpen.de

info@jesspumpen.de